

Changing the values of the cycles on the Techinjector

1. When power is applied to the Techinjector, the Crouzet M2 will display the Synex identification screen:



2. When this screen is visible, the “OK” button may be pressed to enter the parameters menu:



3. The first changeable option, “Init”, will be flashing. At this point, you may press the plus or minus buttons to change the focus to a different option if you choose.

4. Once you choose the option you wish to change, press the “OK” button to begin changing that option. Use the plus and minus buttons to increment the value of that option. You may hold the buttons down to increase the rate at which the value changes.

5. You may press the ESC button to undo the changes you have made at this point. Alternatively, you may press the OK button to save the changes to memory. Once you save the changes you have made, you may not undo them. Pressing the OK button will return you to step 3.

* - You may exit the parameters menu by pushing the ESC button until you see the Synex identification screen.

* - Turning the MAIN POWER on while at step three should exit the parameter menu and apply the changes you have already saved. Turning the MAIN POWER on while at step four will cause unpredictable behavior. Save your changes by pushing the OK button or cancel your changes by pushing the ESC button before you turn on MAIN POWER. It is not advised to turn on MAIN POWER while editing run times.